Installation and Operating Guide | Warranty

Model Number | C34W37 | Direct View TV

© Copyright 2003, Zenith Electronics Corporation.

zenith

WARNING

RISK OF ELECTRIC SHOCK
DO NOT OPEN

WARNING:

TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:

TO PREVENT FIRE OR SHOCK HAZARDS, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

POWER CORD POLARIZATION:

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

ATTENTION: POUR ÉVITER LES CHOCS ÉLECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU FOND.

NOTE TO CABLE/TV INSTALLER:

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the National Electric Code (U.S.A.). The code provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of the cable entry as practical.

REGULATORY INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

COMPLIANCE:

The responsible party for this product's compliance is:
Zenith Electronics Corporation, 2000 Millbrook Drive, Lincolnshire, IL 60069, USA

Digital TV Hotline:
1-847-941-8000

CAUTION:

Do not attempt to modify this product in any way without written authorization from Zenith Electronics Corporation. Unauthorized modification could void the user's authority to operate this product.

©2003 Zenith Electronics Corporation. All rights reserved.

IMPORTANT SAFETY INSTRUCTIONS

Important safeguards for you and your new product

Your product has been manufactured and tested with your safety in mind. However, improper use can result in electrical shock or fire hazards. To avoid defeating the safeguards that have been built into your new product, please read and observe the following safety points when installing and using your new product, and save them for future reference.

Observing the simple precautions discussed in this manual can help you get many years of enjoyment and safe operation that are built into your new product.

This product complies with all applicable U.S. Federal safety requirements, and those of the Canadian Standards Association.

1. Read Instructions

All the safety and operating instructions should be read before the product is operated.

2. Follow Instructions

All operating and use instructions should be followed.

3. Retain Instructions

The safety and operating instructions should be retained for future reference.

4. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

5. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. Water and Moisture

Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.

7. Accessories, Carts, and Stands

Do not place this product on a slippery or tilted surface, or on an unstable cart, stand, tripod, bracket, or table. The product may slide or fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

8. Transporting Product

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.

PORTABLE CART WARNING

9. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

10. Ventilation

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

11. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

12. Power-Cord Polarization

This product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

13. Power-Cord Protection

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

(Continued on next page)

IMPORTANT SAFETY INSTRUCTIONS

(Continued from previous page)

14. Outdoor Antenna Grounding

If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded to provide protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code (U.S.A.), ANSI/ NFPA 70 provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

Example of Grounding According to National Electrical Code Instructions


Ground Clamp
Antenna Lead in Wire
Antenna Discharge Unit (NEC Section 810-20)
Grounding Conductor (NEC Section 810-21)
Electric Service Equipment
Ground Clamps
Power Service Grounding Electrode System (NEC Art 250, Part H)

Fig. 1

NEC - National Electrical Code

15. Lightning

For added protection for this product (receiver) during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

16. Power Lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

17. Overloading

Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

18. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

19. Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

20. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

a. If the power-supply cord or plug is damaged.

b. If liquid has been spilled, or objects have fallen into the product.

c. If the product has been exposed to rain or water.

d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.

e. If the product has been dropped or the cabinet has been damaged.

f. If the product exhibits a distinct change in performance.

21. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

22. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

23. Wall or Ceiling Mounting

The product should be mounted to a wall or ceiling only as recommended by the manufacturer. The product may slide or fall, causing serious injury to a child or adult, and serious damage to the product.

24. Heat

The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

Table of Contents

Safety Warnings 2
Important Safety Instructions 3-4

Step 1. Hook Up TV

Front Panel Controls 6
Rear Connections Panel 7
Front Connections Panel (Front Video) 8
ANT/Cable Service Hookup 9
Cable Box Connections 10
VCR Connections 11
DVD Player 12
Set-top Box Hookup 13
Monitor Out Setup 14
External Stereo 15
Digital Audio Output 16
Turning the TV on 17
On-Screen Displays 17
Remote Control Functions in TV Mode 18-19

Step 2. Customize your TV's Features

SETUP Menu

EZ Scan (Channel Search) 20-21
Channel Edit 22
DTV Signal 23
Channel Label Setup 24
Main Picture Source Selection 25
PIP (Picture-In-Picture) Options 26-27
POP (Picture-out-of-Picture) Source 28
Multi Point Zooming 28
Twin Picture 29

VIDEO Menu

EZ Picture 30
Manual Video Control 31
Color Temperature 32
Z-View 32
Video Preset 32

AUDIO Menu

Audio Language 33
EZ SoundRite 33
Stereo/SAP Broadcasts Setup 34
EZ Sound 34
Manual Sound Control 35
Turn TV Speakers on/off 35
Front Surround 36

TIME Menu

Auto Clock Setup 37
Manual Clock Setup 38
TV Turn Off Time Setup 39
TV Turn On Time Setup 40
Sleep Timer Setup 41
Auto off 42

OPTION Menu

Aspect Ratio Control 43
Closed Captions 44-45
Caption Option Menu 46
On-Screen Menus Language 47
Velocity Modulation 47
Tilt 48
Degaussing the screen 48
EZ Demo 49

LOCK Menu

Parental Lock Setup 50-51

Step 3. Miscellaneous

Programming the Remote 52
Programming Codes 53-56
Maintenance 57-58
Troubleshooting 59-60
Glossary 61-62
Product Specifications 63
Warranty . . . . . .Back cover

Front Panel Controls



1 Power

2 Standby indicator (Illuminates brightly when the TV is in standby mode. Dims when the TV is switched on.)

3 Remote control sensor

4 TV/VIDEO

5 Menu

6 VOL LEFT / RIGHT
Volume(▶) button increases the sound level and volume(◀) button decreases the sound level.

7 CH (Channel) UP / DOWN

T *h*
e *s*

Rear Connections Panel

Connecting external equipment to your TV.



Digital Audio Output Optical
Connects to external audio equipment like a home theater system.

Digital Audio Input1 Optical
Connects to digital audio from various types of equipment.

Digital Audio Input2 Optical
Used in audio connection from a DTV source.

DVI-HDTV Input
Used to connect from a DTV source.

RF Connectors: Antenna 1 Input, Antenna 2 Input
Used to connect cable or antenna signals to the television, either directly or through your cable box.

Monitor Out
Connects to a second TV or Monitor.

Variable Audio Out
Used to connect either an external amplifier, or add a sub-woofer to your surround sound system.

Component Left/Right Audio
Used for stereo sound from various types of equipment.

Y, P_B, P_R
DVD Component Video and HD Component Video
Some top-of-the-line DVD players use what is called "component video," for extremely accurate picture reproduction. *Refer to your DVD manual for further information.*

S-Video In
A connection available with some high-end equipment that provides even better picture quality for Video 1, 2.

Video 1, 2 and 3 Inputs
Connects the video signals from various types of equipment.

Left/Right Audio
Used for stereo sound from various types of equipment.

Mini glossary

JACK	A connection on the back of a TV, VCR, or any other A/V device. This includes the RF jack and the Audio/Video jacks that are color-coded.
SIGNAL	Picture and sound traveling through cable, or over the air, to your television screen.

Front Connections Panel (Front Video)

There are four jacks on the lower-right front side of your TV that make connecting Audio/Video devices like video games and camcorders very simple.

The jacks are like those found on the back jack connection panel. This means that most equipment that connects to those types of jacks on the rear jackpack, may be connected to the front connection panel (Front Video).

To use the front jacks as the signal source, select them using Main input menu as described on page 25. They will be named "Front Video" in the Main input menu.



S-Video
A connection available on some very high-end equipment that provides better picture quality than video input.

Left/Right Audio
Used for stereo sound from various types of equipment.

Video in
Connects the video signals from any piece of equipment.

hW

Mini glossary

A/V CABLES	Audio/Video cables. Three cable connector—Right audio (red), Left audio (white), and Video (yellow). A/V cables are used for stereo playback of videocassettes and for higher quality picture and sound from other A/V devices.
A/V DEVICE	Any device that produces video (picture) and/or audio (sound) (VCR, DVD, cable box, or television).

Antenna / Cable Service Hookup

1 Connect an antenna and/or cable service to your TV as shown.

2 Turn to page 20 to do a channel search with EZ Scan.



If you receive your RF signal through an

Mini glossary

TV	OVER-THE-AIR SIGNALS	**DTV**	DIGITAL OVER-THE-AIR SIGNALS
CATV	CABLE SIGNALS	**CADTV**	DIGITAL CABLE SIGNALS

Combined signals

TV/CATV/DTV	Over-the-air, cable, and digital over-the-air signals
TV/CATV/CADTV	Over-the-air, cable, and digital cable signals

CAUTION : If you are not sure of the type of signal(s) you are receiving, let EZ Scan complete all the channel signal-type searches. The TV will let you know when the analog, cable, and digital channel scans are complete.

For best signal reception, it is recommended to have your Antenna professionally adjusted.

Cable Box Connections

1 Locate the output jack on the back of your cable box. Connect this to the Antenna 1 jack on the back of your TV.

Or find the composite video and audio jacks on the back of your cable box, and connect them following the instructions provided with your equipment.
This can be combined with any other equipment you may want to hook up.



I f y o u ' r

VCR Connections

1 Locate the Antenna 1 jack on the back of your TV. Connect this to out jack on the back of your VCR.

Or find the composite video and audio jacks on the back of your VCR, and connect them following the instructions provided with your equipment.

You may connect either the composite video or the S-Video cables to your TV. (Do not connect BOTH the composite and the S- Video cables. In the event that you connect both composite and the S-Video cables, only the S-Video will work.)



T o
h e a r
s t e r

I
f
y o u w a n t t o
r e c

A f t
e r
c o n n

DVD Player

1 Find the component or S-Video jacks for video connections, depending on your DVD connectors. Then make the corresponding audio connections. See the diagram for either set up.

2 You may connect either the composite video or the S-Video cables to your TV. Do not connect both the composite and the S-Video.



- **Component Input ports**
  You can get better picture quality if you connect DVD player with component input ports as below.

Component input jacks on the TV	Y	P_B	P_R
Video output jacks of DVD player	Y Y Y Y	Pb B-Y Cb P_B	Pr R-Y Cr P_R

Mini glossary

COMPONENT VIDEO — Some video equipment uses three separate lines (Y, P_B, P_R) to more precisely reproduce images. Your manual will explain how this relates to your equipment.

Set-top box Hookup

1 Find the audio and Y, P_B, P_R jacks or DVI output port on the back of your set-top box and connect them following the instructions provided with your equipment.

2 Connect these cables to your TV as shown.



T h e

DVI

1920x1080i
1280x720p
720x480p

Component 1 (or 2) Input

Y P_B P_R
1920X1080i
1280X720p
720X480p
720X480i

Monitor Out Setup

1 Your TV has a special signal output capability which allows you to hook up a second TV or monitor.

2 Just connect the second TV or monitor to the Monitor output Audio/Video jacks located on the back of your TV. See the Operating Manual of the second TV or monitor for further details regarding that device's input settings.



D
T *V*

External Stereo

H o o k u p V a r i a b l

1 Locate the Variable Audio Out jacks on the back of your TV and the Input jacks on the back of your stereo's amplifier.

2 Connect the two jacks, making sure that the right and left channels are connected correctly.

3 Set up your speakers through your analog stereo amplifier, according to the instructions provided with the amplifier.



Digital Audio Output

Send the TV's audio out to external audio equipment (stereo system) via the Digital Audio Output Optical port.

1 Connect one end of an optical cable to the TV Digital Audio Optical Output port.

2 Connect the other end of the optical cable to the digital audio optical input on the audio equipment.

See the external audio equipment instruction manual for operation.

Caution: Do not look into



Turning the TV On

1 First, connect antenna cable and power cord correctly. At this moment, the TV switches to standby mode.

In standby mode to turn TV on, press the POWER, CH UP/DOWN, TV/VIDEO, FRONT, COMP/DVI or number buttons on the remote control or POWER, TV/VIDEO or CH UP/DOWN on the TV.

2 Select the viewing source by using TV/VIDEO, COMP/DVI or FRONT buttonon the remote control.

This TV is programmed to remember which mode it was last set to, even if you turn the TV off.
Note: See page 20 if you have not auto programmed the TV to receive channels in your local broadcast area.

3 When finished using the TV, press the POWER button on the remote control. The TV reverts to standby mode.

I *f*

On-Screen Displays

This page describes your on-screen display and information banner options.



Main Channel Display
Displays current channel number.

Main Channel Label
Displays current channel label.

PIP Display
This display appears when PIP is active.

Mute
Appears when sound is muted.

Volume
Volume level is displayed while adjusting the sound.

Time
Appears when pressing the enter button on remote control.

Remote Control Functions in TV Mode

MODE
Selects the remote operating mode: TV, VCR, Cable, DVD or Satellite. Select other operating modes, for the remote to operate external devices.

TV/VIDEO
Selects: DTV, Analog, Video1, Video2, Video3, Front video, Component 1-2, and DVI input sources.

FRONT
Selects the front video input sources.

MUTE
Switches the sound on or off

AUDIO
Selects MTS sound: Mono, Stereo, and SAP. Change the audio language in DTV mode.

PIP
Switches between PIP, POP (Picture-out-of-Picture) and Twin picture mode.

PIPCH-
Changes to next lower PIP channel

THUMBSTICK
Allows you to navigate the on-screen menus and to adjust the system settings and preferences, by moving to an option with◄▲▼► and selecting the highlighted option with◎.

MENU
Brings up the main menu to the screen.



MODE INDICATOR LIGHTS
Show active remote mode every time any button is pressed.

LIGHT
Illuminates the remote control buttons.

COMP/DVI
Selects: Component 1, Component 2, and DVI input sources.

SURF
Use to scroll the Surf channel list.

VIDEO
Adjusts the factory preset picture according to the room.

PIP INPUT
Selects the input source for the sub picture.

PIPCH+
Changes to next higher PIP channel.

CC
Lets you select a closed caption mode for displaying captioning information when provided for DTV/Analog signal.

EXIT
Clears all on-screen displays and returns to TV viewing from any menu.

Remote Control Functions in TV Mode



RATIO
Changes the aspect ratio.

SIGNAL
Displays the digital signal strength.

NUMBER KEYPAD
For direct channel selection and programming functions.

DASH
Is used to enter a program number for multiple program channels such as 2—1,2—2,etc.

VOLUME UP/DOWN
Increases/decreases the sound level.

INFO
When you watch the TV, displays information on top of the screen. Not available in Component 1-2 and DVI.

TIMER
Lets you select the amount of time before your TV turns itself off automatically.

RECORD, PAUSE, REW, FFWD, PLAY, STOP
Control the functions on your VCR.

POWER
Turns your TV or any other programmed equipment on or off, depending on mode.

FREEZE
Captures and freezes the currently-viewed picture. Main picture is frozen in PIP or Twin picture mode.

FLASHBK
Tunes to the last channel viewed.

CHANNEL UP/DOWN
Scrolls through available channels present in EZ Scan memory.

SWAP
Swaps the signal from your PIP window to the main screen.

ENTER
When in the menu system and other on-screen displays, selects highlighted options.

SKIP LEFT/RIGHT
Playing CDs: Selects songs.
Playing DVDs: Selects movie chapters.

EZ Scan (Channel Search)



0 *0* *0* *0*

A u t o m a t i c a l l y f i n d s

1 Use pages 9-13 to connect external equipment to your TV. If you have not done so, plug in your TV to a standard 120V, 60Hz power outlet.



2 If you have not done so, remove the back of the remote and put in two AA batteries. Make sure batteries are properly installed (check the +/– symbols).



3 With the remote control in hand, press the POWER button to turn your TV on.



EZ Scan continued

4 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu

5 Press the RIGHT arrow button to access the Setup menu.

6 Use the UP/DOWN arrow button to select EZ Scan, then press the RIGHT arrow button.

7 Use the UP/DOWN arrow button to select option 1, 2, 3, or 4. (Based on your connection(s) to Antenna 1-2.)

8 Press ENTER button to begin the channel search. Note: Allow EZ Scan to complete the channel search cycle for TV, CABLE*, DTV, etc.

R u n
ZE

Mini glossary

TV	The antenna device receiving the program signal sent over-the-air.
DTV	Digital TV programming sent over-the-air.
CATV	Your EZ Scan selection, if you subscribe to a cable service.
CADTV	Your EZ Scan selection, if you subscribe to a digital cable service.

*Cable Service Band Note: Select Std=Standard, HRC=HRC Band, or IRC=IRC Band.

For further band information, contact your cable service provider.

Channel Edit

Create two different sets of channel lists in memory

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

2 Press the RIGHT arrow button to access the Setup menu.

3 Use the UP/DOWN arrow button to select CH.Edit and then press the RIGHT arrow button.

4 You will now see a screen filled with channel numbers and a preview picture. Use the UP/DOWN and LEFT/RIGHT arrow button to select a channel, then use the ⊙ button to add or delete it. Press SURF to add the channel to the Surf List.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



CATV is available

DTV Signal

Lets you know

Using the SIGNAL button

1. Press the SIGNAL button on the remote control.
2. View the on-screen signal strength monitor to see the quality of the signal being received.
3. Press EXIT button to return to TV viewing.

Using the menu

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.
2. Press the RIGHT arrow button to access the Setup menu.
3. Use the UP/DOWN arrows to select the DTV Signal. Current signal strength is shown on menu.
4. Press EXIT button to return to TV viewing.



NOTE: Blank areas

Channel Label Setup



Choose preset labels for

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

2 Press the RIGHT arrow button to access the Setup menu.

3 Use the UP/DOWN arrow button to select CH.Label and then press the RIGHT arrow button.

4 You will now see a screen filled with Labels and a preview screen. Use channel UP/DOWN button on your remote control to select the a channel to Label.

5 Use the UP/DOWN and LEFT/RIGHT arrows to select the appropriate label for the channel and press ⊙ to set the Label to the selected channel.

6 Repeat 4 and 5 steps until all channels are Labeled.

7 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



The TV Disc

Main Picture Source Selection

N o t e : T h i s T V i s e q u i p p e d w i t h P i c t u r

Using the TV/VIDEO, FRONT, and COMP/DVI button

1 Use the TV/VIDEO, FRONT, and COMP/DVI button to select the input source.

Each time you press TV/VIDEO button, you toggle between DTV, Analog, Video 1, Video 2, Video 3, Front Video, Component 1, Component 2, and DVI.
Each time you press FRONT button, you toggle between connected Front Video sources.
Each time you press COMP/DVI button, you toggle between Component 1, Component 2, and DVI.

Using the menu

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

2 Press the RIGHT arrow button to access the Setup menu.

3 Use the UP/DOWN arrows to select the Main Input option.

4 Press the RIGHT arrow to access the Main Input menu, then use the UP/DOWN arrow button to select the source. Your Main picture source options are : DTV, Analog, Video 1, Video 2, Video 3, Front video, Component 1, Component 2, and DVI.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



PIP (Picture-In-Picture) Options

P I P
l e t s y o u
v i e w 2
d i f-

Watching PIP

Press the PIP button to show the sub picture.
Each press of PIP changes the PIP options as shown below.



PIP Source Selection

C h a n g e s
t h e
p i



Using the PIP INPUT button

1 Use the PIP INPUT button to select the input source for the sub picture.
Each time you press PIP INPUT button, you toggle between DTV, Analog, Video 1, Video 2, Video 3, and Front Video.

Using the menu

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

2 Press the RIGHT arrow button to access the Setup menu.

3 Use the UP/DOWN arrows to select the Sub Input option.

4 Press the RIGHT arrow to access the Sub Input menu, then use the UP/DOWN arrow button to select the source. Your choices are: DTV, Analog, Video 1, Video 2, Video 3, and Front Video.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

D o
n o t
d i s
p l a y a
f
i x
o d u
m n a ' g t

PIP (Picture-In-Picture) Options

Selecting PIP Channels

1 Press the PIP button.

2 Select the Analog or DTV option on the Sub input menu or with the PIP INPUT button. Use the PIPCH-/PIPCH+ button to select a channel for the sub picture.

Swapping Screen

Press the SWAP button.
Each time you press the SWAP button, you switch the Main and PIP pictures.



Moving the Sub Picture

In the PIP mode, each press of the UP/DOWN/LEFT/RIGHT arrow button will move the sub picture to a different position on the screen.

POP (Picture-Out-Of-Picture) Source

U s
e
P 0

1 Press PIP on the remote control with the PIP image on the screen to activate POP (Picture-out-of-Picture) mode.
The pictures of all the programmed channels are searched with the 3 PIP screen, as shown to the right.

- Channel selection: Press LEFT arrow button to enlarge the selected channel being searched on the PIP screen to view it on the Main screen.
- PIP selection: Use UP/DOWN arrow button to select one of 3 PIP screen pictures in POP mode.
- Input source selection for PIP: Use PIP INPUT button or Sub input of Setup menu to select input souce for sub picture (You can't select DTV for main and sub picture simultaneously).

2 Press the EXIT button to exit POP mode.

R u n
ZE
S c

Multi Point Zooming

1 In DTV 720p/1080i mode, press the FREEZE button.

2 Use UP/DOWN/LEFT/RIGHT arrow button to select the screen split zoom section.

3 Press the FREEZE/RATIO button to return to TV viewing or press the EXIT button to return to a frozen picture again.

Twin Picture

T w i n P i c t u r

Watching Twin Picture

1 Press the PIP button on the remote control in POP mode to activate twin picture mode.
Select the Analog or DTV option on the Sub input menu or with the PIP INPUT button.
Use the PIPCH-/PIPCH+ button to select a channel for the sub picture.

2 Press the EXIT button to exit twin picture mode.

Swapping Screen

Press the Swap button.
Each time you press SWAP, you switch the PIP and Main screen channels.



Adjusting Sub Picture Size

Use the UP/DOWN/LEFT/RIGHT arrow button to adjust main and sub picture size in twin Picture mode.

Selecting an Input Signal Source for Sub Picture

Use the PIP INPUT button to select the input source for the sub picture.
Each time you press PIP INPUT, you toggle between DTV, Analog, Video 1, Video 2, Video 3, and Front Video.

VIDEO Menu

Each video o

EZ Picture

This function adjusts the TV to the best picture

Choose the

Using the VIDEO button

1 Use the VIDEO button to select EZ Picture option.

Each press of the VIDEO button change the EZ Picture option: Off, Normal, Digital Preset, Night Time, Movie, Weak Signal, Video Game, and Sports.

2 Press EXIT to save and return to TV viewing.

Using the menu

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Video menu.

2 Press the RIGHT arrow button to access the Video menu.

3 Use the UP/DOWN arrows to select the EZ Picture option.

4 Press the RIGHT arrow to access the EZ Picture menu, then use the UP/DOWN arrow button to select the options: Off, Normal, Digital Preset, Night Time, Movie, Weak Signal, Video Game, and Sports.

- **Off:** Allows you to adjust the picture the way you want.
- **Normal:** Resets all the options to their preset values.
- Other options adjust the picture to the source's image.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



VIDEO Menu

Manual Video Control

Adjust the picture



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Video menu.

2 Press the RIGHT arrow button to access the Video menu.

3 Use the UP/DOWN arrow button to select one of the following options: Contrast, Brightness, Color, Sharpness, or Tint, then press the RIGHT arrow button.

- **Contrast:** Adjusts the difference between the light and dark levels of the picture.
- **Brightness:** Adjusts the white or light level of the overall picture.
- **Color:** Adjusts the intensity of all colors.
- **Sharpness:** Adjusts the level of crispness in the edges between the light and dark areas of the picture. The lower the level, the softer the image.
- **Tint:** Adjusts the balance between the red and green levels.

4 Use the LEFT/RIGHT arrow button to adjust the option to your preference. Use the UP/DOWN arrow button to select another option.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

You can manually adjust



VIDEO Menu

Color Temperature

Lets you choose one of

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Video menu.
2. Press the RIGHT arrow button to access the Video menu.
3. Use the UP/DOWN arrow button to select Color Temperature, and then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to select Warm, Medium, or Cool.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Z-View

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Video menu.
2. Press the RIGHT arrow button to access the Video menu.
3. Use the UP/DOWN arrow button to select Z-View, and then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to select Off or On. On, automatically adjusts the picture display for optimum quality.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Video Preset

This is the

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Video menu.
2. Press the RIGHT arrow button to access the Video menu.
3. Use the UP/DOWN arrow button to select Video Preset.
4. Use the RIGHT arrow button to preset the video configuration.



AUDIO Menu

Audio Language

Other languages may be available

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Audio menu.
2. Press the RIGHT arrow button to access the Audio menu.
3. Use the UP/DOWN arrow button to select Audio Language, then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to select the language you wish.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

EZ SoundRite

Scans for changes in sound

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Audio menu.
2. Press the RIGHT arrow button to access the Audio menu.
3. Use the UP/DOWN arrow button to select EZ SoundRite, then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to select On or Off.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

AUDIO Menu

Stereo/SAP Broadcasts Setup

This TV can

1 Use the AUDIO button to select your desired MTS mode. Each time you press the AUDIO button, MONO, STEREO, or SAP appear in turn.

2 Press EXIT to save and return to TV viewing.

Stereo or SAP
Mono sound is automatically recei
Select MONO if

EZ Sound

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Audio menu.

2 Press the RIGHT arrow button to access the Audio menu.

3 Use the UP/DOWN arrows to select the EZ Sound option.

4 Press the RIGHT arrow to access the EZ Sound menu, then use the UP/DOWN arrow button to select the options: Off, Normal, Stadium, News, Music and Theater.

- **Off:** Allows you to adjust the picture the way you want.
- **Normal:** Resets all the options to their preset values.
- Other options adjust the TV's audio output to the source's sound.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

This function lets you enjoy the

Choose the

AUDIO Menu

Manual Sound Control

A d j u s t t h e

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Audio menu.

2 Press the RIGHT arrow button to access the Audio menu.

3 Use the UP/DOWN arrow button to select one of the following options: Balance, Treble, or Bass, then press the Right arrow button.

- **Bass:** Increases or decreases the lower frequency sounds from the TV speakers.
- **Treble:** Increases or decreases the higher frequency sounds from the TV speakers.
- **Balance:** Lets you adjust the left to right balance of the TV speakers.

4 Use the LEFT/RIGHT arrow button to adjust the option to your preference. Use the UP/DOWN arrows to select another option.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

Turn TV Speakers On/Off

T u r n s

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Audio menu.

2 Press the RIGHT arrow button to access the Audio menu.

3 Use the UP/DOWN arrow button to select TV Speaker, then press the RIGHT arrow button.

4 Use the UP/DOWN arrow button to select On or Off.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

AUDIO Menu

SRS is a trademark

Manufactured under

Front Surround

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Audio menu.
2. Press the RIGHT arrow button to access the Audio menu.
3. Use the UP/DOWN arrow button to select Front Surround, then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to select Off, 3D EchoSound System or SRS (Sound Retrieval System) TruSurround XT.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Mini glossary

SRS TruSurround XT

Takes advantage of any multi-channel format without needing to add extra speakers or equipment. Dialog clarity, bass enrichment and the addition of stereo audio enhancement that produces an immersive sound experience from standard stereo material.

3D EchoSound System

Creates a stunning simulated stereo effects from any mono sound and a realistic three-dimensional sound with a very wide and deep sound stage into stereo sound.

Auto Clock Setup

Set the time automatically through



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu option.

2 Press the RIGHT arrow button to go to the Time menu.

3 Use the UP/DOWN arrow button to choose Auto Clock, then press the RIGHT arrow button.

4 Use the UP/DOWN arrow button to choose On, then use the RIGHT arrow button to select Time Zone.

5 Use the UP/DOWN arrow button to adjust Time Zone.

- Select the time zone for your viewing area. Your options are: Eastern, Central, Mountain, Pacific, Alaska, Hawaii.

6 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Manual Clock Setup

I f c u r r e n t t i m



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu option.

2 Press the RIGHT arrow button to activate the Time menu.

3 Use the UP/DOWN arrow button to choose Manual Clock, then press the RIGHT arrow button.

4 Use the LEFT/RIGHT arrow button to select either the year, hour or minutes option. Once selected, use the UP/DOWN arrow button to set the year, hours or minutes.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



TV Turn Off Time Setup

Lets you set an automatic daily turn off time



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press the RIGHT arrow button to to go to the Time menu.

3 Use the UP/DOWN arrow button to choose Off Timer, then press the RIGHT.

4 Use the UP/DOWN arrow button to choose On, then press the RIGHT arrow button.

5 Use the LEFT/RIGHT arrow button to select the hour or minutes options, then use the UP/DOWN arrow button to set the hours or minutes.

6 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



TV Turn On Time Setup

Lets you set an automatic daily turn on time for your TV. Off



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press the RIGHT arrow button to activate the Time menu.

3 Use the UP/DOWN arrow button to choose On Timer, then press the RIGHT arrow button.

4 Use the UP/DOWN arrows to choose On, then press the RIGHT arrow button.

5 Use the LEFT/RIGHT arrow button to select either Time, Channel, or Volume. Once selected, use the UP/DOWN arrow button to set either the Time, Channel, or Volume options.

6 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

To cancel On T



Sleep Timer Setup

L e t s y o u s e l



Using the TIMER button

1 Press the TIMER button on the remote control repeatedly to select the number of minutes.

First the Off option will appear on the screen, followed in sequence 10, 20, 30, 60, 90, 120, 180, and 240. The timer begins to count down from the number of minutes selected.

2 Press EXIT button to save and return to TV viewing

Using the menu

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press the RIGHT arrow button to go to the Time menu.

3 Use the UP/DOWN arrow button to choose Sleep Timer then press the RIGHT arrow button.

4 Use the UP/DOWN arrows to choose a pre-set turn off time.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



W h e n t h e s l e

T o

T o dhang

I f

Auto Off

If there is no input signal,



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press the RIGHT arrow button to go to the Time menu.

3 Use the UP/DOWN arrow button to choose Auto Off then press the RIGHT arrow.

4 Use the UP/DOWN arrows to choose On or Off.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Aspect Ratio Control

Lets you choose the way that an analog picture

Using the RATIO button

1 Use the RATIO button to select the desired picture format.

Each press of the RATIO button changes the picture format. Your options are: Set By Program, 4:3, 16:9, Horizon, Zoom1, Zoom2, and Cinema Zoom.

2 Press EXIT to save and return to TV viewing.

Using the menu

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.

2 Press the RIGHT arrow button to go to the Option menu.

3 Use the UP/DOWN arrows to choose the Aspect Ratio option, then press the RIGHT arrow button.

4 Use the UP/DOWN arrow button to select the desired picture format.

- Use the UP/DOWN arrow button to adjust the enlarge proportion of Cinema Zoom. The adjustment of range is 1~16.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

When you receive a picture

Mini glossary

Set By Program	Selects the proper picture proportion to match the source's image. (4:3 → 4:3, 16:9 → 16:9)
4:3	Choose when you want to view a picture with an original 4:3 aspect ratio, with black bars appearing at both the left and right sides.
16:9	Choose when you want to adjust the picture horizontally, in a linear proportion to fill the entire screen.
Horizon	Choose when you want to adjust the picture in a non-linear proportion, that is, more enlarged at both sides, to create a spectacular view.
Zoom1	Choose when you want to view the picture without any alteration. However, the top and bottom portions of the picture will be cropped.
Zoom2	Choose when you want the picture to be altered, both horizontally extended and vertically cropped. The picture taking a halfway trade off between alteration and screen coverage.
Cinema Zoom	Choose when you want to enlarge the picture in correct proportion. When enlarging or reducing the picture, the image may become distorted.

Closed Captions

Select a caption mode for display in captioning

This is

Using the CC button

1 Use the CC button to select caption.

Each press of the CC button changes the caption option; Off, CC1, CC 2, CC 3, CC 4, Text 1, Text 2, Text 3, or Text 4.

2 Press EXIT to save and return to TV viewing.

Using the menu

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.

2 Press the RIGHT arrow button to activate the Option menu.

3 Use the UP/DOWN arrow button to choose Caption, then press the Right arrow button.

4 Use the UP/DOWN arrow button to make your caption selection. Your choices are: Off, CC1, CC 2, CC 3, CC 4, Text 1, Text 2, Text 3, or Text 4.

5 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Mini glossary

CAPTIONS	The term for the words that scroll across the bottom of the TV screen; usually the audio portion of the program provided for the hearing impaired.
TEXT	The term for the words that appear in a large black frame and almost cover the entire screen; usually messages provided by the broadcaster.

Closed Captions (Continued)

Choose the language you want the DTV/CA

Using the CC button

1. Press the CC button repeatedly to scroll and select available caption languages.
2. Press EXIT to save and return to TV viewing.

Using the menu

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.
2. Press the RIGHT arrow button to access the Option menu.
3. Use the UP/DOWN arrows to select the Caption, then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to choose any of the following options : Off, English, Spanish, or French.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Caption Option Menu

C u s t o m i z e



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.

2 Press the RIGHT arrow button to access the Option menu.

3 Use the UP/DOWN arrows to select the Caption Option, then press the RIGHT arrow button.

4 Use the LEFT/RIGHT arrow button to select Custom.

5 Use UP/DOWN arrow button to customize the Style, Font, etc., to your preference. Your Caption options are:

- **Size:** Set the size the words will appear in.
- **Font:** Select a typeface for the words.
- **Text Color:** Choose a color for the text.
- **Text Opacity:** Specify the opacity for the text color.
- **Bg (Background) Color:** Select a background color.
- **Bg (Background) Opacity:** Select the opacity for the background color.
- **Edge Type:** Select an edge type.
- **Edge Color:** Select a color for the edges.

6 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



A p e r v

On-Screen Menus Language

Select

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.
2. Press the RIGHT arrow button to go to the Option menu.
3. Use the UP/DOWN arrows to choose the Language, then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to select the language you want the on screen menus to appear in.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

Velocity Modulation

Use this function

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.
2. Press the RIGHT arrow button to access the Option menu.
3. Use the UP/DOWN arrow button to select VM, and then press the RIGHT arrow button.
4. Use the UP/DOWN arrow button to select Off, Low, or High.
5. Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

Tilt

T h e p i c t u r e



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.

2 Press the RIGHT arrow button to access the Option menu.

3 Use the UP/DOWN arrow button to select Tilt, then, use the LEFT/RIGHT arrow button to adjust and correct any Tilt.

4 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

Degaussing the Screen

T h e m a g- n e t i c f i e l d

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.

2 Press the RIGHT arrow button to access the Option menu.

3 Use the UP/DOWN arrow button to select Degauss, then press the RIGHT arrow button to perform the Degauss function.

4 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.

I f

EZ Demo

Shows you how to view



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Option menu.

2 Press the RIGHT arrow button to access the Option menu.

3 Use the UP/DOWN arrow button to select EZ Demo, then press the RIGHT arrow button.

4 Press EXIT button on the remote to stop EZ Demo.



Parental Lock Setup

Lets you set up block

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Lock Menu option.

2 Press the RIGHT arrow button to activate the Lock Menu.

3 Use the UP/DOWN arrows to choose from the following Lock Menu options. Once the options are selected, change the settings to your preferences.

- **Lock On/Off**: Activates or disables the blocking scheme you set up previously.
- **Set Password:** Change the password by inputting a new password twice.
- **Movie Rating (MPPA):** Blocks movies according to the movie ratings limits specified, so children cannot view certain movies. You can set the ratings limit by blocking out all the movies with the ratings above a specified level. Keep in mind that the movie ratings limit only applies to movies shown on TV, not TV programs, such as soap operas.
- **TV Rating-Children**: Keeps children from watching certain TV programs among only the programs intended for children, according to the ratings limit. The children rating does not apply to other TV programs. Unless you block certain TV programs intended for mature audiences in the TV Rating - sub menu, your children can view those programs.
- **TV Rating-General**: Blocks certain TV programs that you and your family do not want to view, based on the ratings.
- **Aux. Block**: Enables you to select a source for blocking among the source devices you have hooked up.

4 Press EXIT button to return to TV viewing or press MENU button to return to the previous menu.



Parental Lock Rating Descriptions

TV-Y (All Children): Program is appropriate for all children.

TV-Y7 (Directed toward Older Children): Program is designed for children age 7 and above.

TV-G (General audience): Most parents would find this program suitable for all ages.

TV-PG (Parental guidance suggested): Program contains material that parents may find unsuitable for younger children.

TV-14 (Parents strongly cautioned): Program contains some material that many parents would find unsuitable for children under 14 years of age.

TV-MA (Mature audience only): Program is specifically designed to be viewed by adults and therefore may be unsuitable for children under 17.

G (General audiences): All ages can view these programs.

PG (Parental guidance suggested): Some program content may not be suitable for children.

PG-13 (Parents strongly cautioned): Some program content may not be appropriate for children under 13.

R (Restricted): Children under 17 requires parent or adult guardian to be present.

NC-17: No one 17 should be allowed to view the program.

X: For Adult viewing only.

Programming the Remote

The remote control for your HD receiver is a multi-brand or universal remote control. It can be programmed to operate most remote-controllable devices of other manufacturers.

Note that the remote control may not control all models of other brands.

1 Test your remote control.
To find out whether your remote control can operate the component without programming, turn on the component such as a VCR and press the corresponding mode button (VCR) on the remote control, while pointing at the component. Test the **POWER** and **CH +/-** buttons to see if the component responds properly. If not, the remote requires programming to operate the device.

2 Turn on the component to be programmed, then press the corresponding mode button on the remote control.

3 Press the POWER and MUTE buttons simultaneously, the remote control is ready to be programmed for the code.

4 There are two ways to find the right code for the component.

A. If you press the **CH +/-** buttons repeatedly, the codes will change one at-a-time. Press the POWER button after each code change. If the right code is found, the device will turn off.

B. Enter a code number using the number buttons on the remote. Programming code numbers for the corresponding component can be found on the following pages.
Again, if the code is correct, the device will turn off.

5 Press the EXIT button to store the code.

6 Test the remote control functions to see if the component responds properly. If not, repeat from step 2.



TVs

Brand	Codes	Brand	Codes	Brand	Codes	Brand	Codes
A MARK	112 143	GOLDSTAR	004 102 106		019 024 040	Sharp	004 014 019
ADMIRAL	072 081 161		110 112 113		056 130 132		022 028 029
AKAI	006 146		116 119 122		134		081 143 170
AMPRO	073 167		127 137 143	NIKEI	043		175
AMSTRAD	052	HALL MARK	004 116	ONKING	043	SIEMENS	088
ANAM	043 054 056	HITACHI	004 006 009	ONWA	043	SIGNATURE	072
	080 104 108		010 011 012	OPTONICA	019 081	SONY	041 070 079
	112 115 118		023 041 075	PANASONIC	034 056 080		085 126 139
	121 131		143 158 163		092 164		147 185
AOC	004 006 058		166	PHILCO	003 004 006	SOUNDESIGN	003 004 028
	112	INFINITY	164		024 043 056		043 116
BLAUPUNKT	088	INKEL	129		059 060 063	SPECTRICON	112
CANDLE	002 003 004	JBL	164		064 127 143	SSS	004 043
	006	JCPENNY	004 006 008		164	SUPRE MACY	002
CAPEHART	058		009 024 030	PHILIPS	003 004 005	SYLVANIA	003 004 006
CETRONIC	043		065 101 143		006 038 059		044 059 060
CITIZEN	002 003 004		156 160		070 093 143		063 064 116
	006 043 101	JENSEN	013		160 164		127 140 160
	103 143	JVC	034 038 070	PIONEER	006 018 023		164
CLASSIC	043		083 145		025 027 116	TANDY	081
CONCERTO	004	KEC	043		135 176	TATUNG	056 062
CONTEC	039 043 050	KENWOOD	006 070	PORTLAND	004 143	TECHNICS	034 080 084
	051	KLOSS	002 059	PROSCAN	144 160 161	TECHWOOD	004
CORONADO	143	KMC	143		165 167	TEKNIKA	002 003 004
CRAIG	043 054	KTV	006 043 143	PROTON	004 058 116		006 024 028
CROWN	043 143		154		131 143 171		031 043 072
CURTIS MATHES	004 006 101	LG	255		173		077 101 103
	116 143	LODGENET	072	QUASAR	034 056 092		143
CXC	043	LOGIK	072	RADIO SHACK	019 043 047	TELEFUNKEN	037 046 086
DAEWOO	004 016 017	LUXMAN	004		116 127 143		087
	043 044 055	LXI	007 015 052	RCA	004 006 023	TELERENT	072
	071 076 103		081 160 164		024 056 065	TERA	172
	107 111 114		166		074 144 152	TMK	004 116
	117 120 123	MAGNAVOX	003 004 006		156 160 161	TOSHIBA	007 015 030
	125 127 128		022 059 060		165		040 051 062
	136 143		061 063 064	REALISTIC	007 019 043		101 138
DAYTRON	004 116 143		127 143 160		047	TOTEVISION	143
DYNASTY	043		164	ROCTEC	186	UNIVERSAL	008 009
DYNATECH	062	MARANTZ	006 077 164	RUNCO	168 169	VIDEO CONCEPTS	146
ELECTROHOME	024 077 143	MATSUI	164	SAMPO	004 006 058	VIDIKRON	174
EMERSON	004 005 006	MEMOREX	004 007 072		116	VIDTECH	004 116
	028 043 047		116	SAMSUNG	004 050 089	WARDS	004 008 009
	048 050 051	METZ	088		101 105 113		019 028 060
	096 116 143	MGA	004 006 024		116 127 133		061 063 064
	151 153 154		028 042 049		137 143 160		072 074 116
	155		077 116	SANYO	007 020 021		143 164
FISHER	007 057	MINERVA	088		033 039 053	YAMAHA	004 006
FUNAI	028 043	MITSUBISHI	004 006 024		057 082 166	YORK	004 116
FUTURETECH	043		028 040 042	SCOTT	004 028 043	YUPITERU	043
GE	004 006 008		109 116 124		048 116 143	ZENITH	001 072 073
	009 034 056		146	SEARS	004 007 015		095 103 157
	073 074 091	MTC	004 006 062		028 030 057	ZONDA	112
	116 130 144		101		082 094 101		
	155 160 161	NAD	015 025		116 143 160		
	165	NEC	006 007 016				

VCRs

Brand	Codes	Brand	Codes	Brand	Codes	Brands	Codes
AIWA	034		055 060 130		034 040 041	TOTEVISION	040 101
AKAI	016 043 046		150 152		062 063 107	UNITECH	040
	124 125 146	KENWOOD	014 034 039		109 140 144	VECTOR RESEARCH	012
AMPRO	072		043 047 048		145 147	VICTOR	048
ANAM	031 033 103	LG	255	REALISTIC	003 008 010	VIDEO CONCEPTS	012 034 046
AUDIO DYNAMICS	012 023 039	LLOYD	034		014 031 033	VIDEOSONIC	040
	043	LXI	003 009 013		034 040 053	WARDS	003 013 017
BROKSONIC	035 037 129		014 017 034		054 101		024 031 033
CANON	028 031 033		101 106	RICO	058		034 040 053
CAPEHART	108	MAGIN	040	RUNCO	148		054 131
CRAIG	003 040 135	MAGNAVOX	031 033 034	SALORA	014	YAMAHA	012 034 039
CURTIS MATHES	031 033 041		041 067 068	SAMSUNG	032 040 102		043
DAEWOO	005 007 010	MARANTZ	012 031 033		104 105 107	ZENITH	001 034 048
	064 065 108		067 069		109 112 113		056 058 072
	110 111 112	MARTA	101		115 120 122		080 101
	116 117 119	MATSUI	027 030		125		
DAYTRON	108	MEI	031 033	SANSUI	022 043 048		
DBX	012 023 039	MEMOREX	003 010 014		135		
	043		031 033 034	SANYO	003 007 010		
DYNATECH	034 053		053 072 101		014 102 134		
ELECTROHOME	059		102 134 139	SCOTT	017 037 112		
EMERSON	006 017 025	MGA	045 046 059		129 131		
	027 029 031	MINOLTA	013 020	SEARS	003 008 009		
	034 035 036	MITSUBISHI	013 020 045		010 013 014		
	037 046 101		046 049 051		017 020 031		
	129 131 138		059 061 151		042 073 081		
	153	MTC	034 040		101		
FISHER	003 008 009	MULTITECH	024 034	SHARP	031 054 149		
	010	NEC	012 023 039	SHINTOM	024		
FUNAI	034		043 048	SONY	003 009 031		
GE	031 033 063	NORDMENDE	043		052 056 057		
	072 107 109	OPTONICA	053 054		058 076 077		
	144 147	PANASONIC	066 070 074		078 149		
GO VIDEO	132 136		083 133 140	SOUNDESIGN	034		
GOLDSTAR	012 013 020		145	STS	013		
	101 106 114	PENTAX	013 020 031	SYLVANIA	031 033 034		
	123		033 063		059 067		
HARMAN KARDON	012 045	PHILCO	031 034 067	SYMPHONIC	034		
HITACHI	004 018 026	PHILIPS	031 033 034	TANDY	010 034		
	034 043 063		054 067 071	TATUNG	039 043		
	137 150		101	TEAC	034 039 043		
INSTANTREPLAY	031 033	PILOT	101	TECHNICS	031 033 070		
JCL	031 033	PIONEER	013 021 048	TEKNIKA	019 031 033		
JCPENNY	012 013 015	PORTLAND	108		034 101		
	033 040 066	PULSAR	072	THOMAS	034		
	101	QUARTZ	011 014	TMK	006		
JENSEN	043	QUASAR	033 066 075	TOSHIBA	008 013 042		
JVC	012 031 033		145		047 059 082		
	043 048 050	RCA	013 020 033		112 131		

SAT

Brand	Codes	Brand	Codes	Brand	Codes	Brand	Codes
ALPHASTAR DSR	123		027 133 134	PERSONAL CABLE	117	VIEWSTAR	115
AMPLICA	050	GENERAL INSTRUMENT	003 004 016	PHILIPS	071	WINEGARD	128 146
BIRDVIEW	051 126 129		029 031 059	PICO	105	ZENITH	001 081 082
BSR	053		101	PRESIDENT	019 102		083 084 091
CAPETRONICS	053	HITACHI	139 140	PRIMESTAR	030 110 111		120
CHANNEL MASTER	013 014 015	HOUSTON TRACKER	033 037 039	PROSAT	072		
	018 036 055		051 057 104	RCA	066 106		
CHAPARRAL	008 009 012	HUGHES	068	REALISTIC	043 074		
	077	HYTEK	053	SAMSUNG	123		
CITOH	054	JANIEL	060 147	SATELLITE SERVICE CO	028 035 047		
CURTIS MATHES	050 145	JERROLD	061		057 085		
DRAKE	005 006 007	KATHREIN	108	SCIENTIFIC ATLANTA	032 138		
	010 011 052	LEGEND	057	SONY	103		
	112 116 141	LG	255	STARCAST	041		
DX ANTENNA	024 046 056	LUTRON	132	SUPER GUIDE	020 124 125		
	076	LUXOR	062 144	TEECOM	023 026 075		
ECHOSTAR	038 040 057	MACOM	010 059 063		087 088 090		
	058 093 094		064 065		107 130 137		
	095 096 097	MEMOREX	057	TOSHIBA	002 127		
	098 099 100	NEXTWAVE	028 124 125	UNIDEN	016 025 042		
	122	NORSAT	069 070		043 044 045		
ELECTRO HOME	089	PACE SKY SATELLITE	143		048 049 078		
EUROPLUS	114	PANASONIC	060 142		079 080 086		
FUJITSU	017 021 022	PANSAT	121		101 135 136		

DVD

Brand	Codes	Brand	Codes	Brand	Codes	Brand	Codes
APEX DIGITAL	022		025	PHILIPS	013	THOMPSON	005 006
DENON	020 014	MAGNAVOX	013	PIONEER	004 026	TOSHIBA	019 008
GE	005 006	MARANTZ	024	PROCEED	021	YAMAHA	009 018
GOLDSTAR	010 016 025	MITSUBISHI	002	PROSCAN	005 006	ZENITH	010 016 025
HARMAN KARDON	027	NAD	023	RCA	005 006		
JVC	012	ONKYO	008 017	SAMSUNG	011 015		
LG	001 010 016	PANASONIC	003 009	SONY	007		

CATV

Brand	Codes	Brand	Codes	Brand	Codes	Brand	Codes
ABC	003 004 039		008 009 010	REGAL	049 050		032 035
	042 046 052		052 069 074	REGENCY	057	VIEWSTAR	012 015 018
	053	LG	255	REMBRANT	025		086 087 088
ANTRONIK	014	M-NET	037	RK	091		089
ARCHER	005 007 014	MACOM	033	SAMSUNG	030 068	ZENITH	001 060 093
	024	MAGNAVOX	010 012 064	SCIENTIFIC ATLANTA	003 011 041		
CABLE STAR	026		079		042 043 045		
CENTURION	092	MEMOREX	001		046		
CENTURY	007	MOVIE TIME	028 032	SHERITECH	022		
CITIZEN	007	NSC	015 028 038	SIGNAL	030		
COLOUR VOICE	065 090		071 073	SIGNATURE	052		
COMBANO	080 081	OAK	016 031 037	SL MARX	030		
COMTRONICS	019 030		053	SPRUCER	047 078		
DIAMOND	023	PANASONIC	044 047	STARCOM	002 004 008		
EAGLE	020 030 040	PARAGON	001		009		
EASTERN	057 062 066	PHILIPS	006 012 013	STARGATE	008 030		
ELECTRICORD	032		020 065 085	SYLVANIA	067		
GE	072		090	TADIRAN	030		
GEMINI	008 022 025	PIONEER	034 051 052	TANDY	017		
	054		063 076	TEXSCAN	029 067		
GI	052 074	POST NEWS WEEK	016	TOCOM	039 040 056		
GOLDEN CHANNEL	030	PRUCER	059	TOSHIBA	001		
HAMLIN	049 050 055	PTS	011 048 071	UNIKA	007 014 024		
HITACHI	052 055		072 073 074	UNITED CABLE	004 053		
HOSPITALITY	070 077	PULSAR	001	UNIVERSAL	005 007 014		
JERROLD	002 003 004	RCA	047		024 026 027		

Early malfunctions can be prevented. Careful and regular cleaning can extend the amount of time you will have your new TV. Be sure to turn the power off and pull out the power cord before you begin any cleaning.

SCREEN CLEANING

1. Here's a great way to keep the dust off your screen for a while. Wet a soft cloth in a mixture of lukewarm water and a little fabric softener or dish washing detergent. Wring the cloth until it's almost dry, and then use it to wipe the screen.
2. Make sure the excess water is off the screen, and then let it air-dry before you turn on your TV.

CABINET CLEANING

1. Use a soft cloth with a mild soap solution to wipe the cabinet.
2. Rinse the cloth and wipe the cabinet again.
3. Let the cabinet air-dry before turning the TV on.

EXTENDED ABSENCE

If you expect to leave your TV dormant for a long time (such as a vacation), unplug the power cord from the wall power outlet to protect against possible damage from lightning or power surges. If you use an off-air antenna, you may also want to disconnect it from the back of your TV before leaving.

PICTURE INTERFERENCE

Even though you may be getting cable, the signal may be weak, which means the quality of your picture may suffer due to other factors. If there are problems with the image on your TV, consult the Troubleshooting guide on the following pages. You may also want to contact your cable service provider to determine if the problem is from the cable service.

VIDEO GAMES AND OTHER FIXED-PATTERN DISPLAYS

If you use your TV to play video games or for other uses that involve single, fixed images, such as a photo-CD player, you should avoid setting the Brightness level too high.
If static images, like network identification icons or patterns, are left on the screen for a long time period, they may leave a permanent impression on the TV screen. You can reduce the chance of this happening by
limiting the amount of time you use the fixed-image display, and by reducing the contrast and brightness levels.

If you unplug your TV, you may have to reset

Troubleshooting

Some quick and easy tips for fixing problems yourself.

SYMPTOM	POSSIBLE SOLUTIONS
Snowy picture and unclear sound.	• Check your antenna connection or location. • Check your cable input. • Check to see if the TV/VCR button on your VCR has the TV selected.
Multiple images or 'ghost shadows.'	• Check your antenna direction and/or location. • Check your cable input. • Make sure the cable from your antenna to your TV is properly connected.
Interference: Sharp lines across the screen and unclear sound.	*The following may cause image problems:*
Normal picture but no sound.	*distortion: Electrical appliances, power-full lights, cars, trucks; computers or portable phones; medical equipment*
No picture and unclear sound.	• If possible increase the distance between your TV and the offending appliance, or shut one of them off.
No picture or sound.	• Check volume levels. • Make sure the TV is not Muted.
No color, but the sound is okay.	• Try another channel. The problem may be with the broadcast, not your TV. • Are the Audio cables installed properly? • Are the wires for external speakers (if you have external speakers) installed properly?
Picture has a big black box on it, but the sound is okay.	• Make sure your speakers are turned on in the Audio menu. • If your audio mode is set to SAP, the program may not have SAP.
Picture has two horizontal black bars, one on top and one on bottom.	• Are you in TV or cable tuning mode, and should be in the other? • Make sure output channels on all A/V equipment are on the same channel (3 or 4). • Check that all connections are tight.
Missing Secret Lock Code	• Is the AC power plugged in? • Check that your AC power cord outlet works. (Test it by plugging in something else or try another power outlet.)

SYMPTOM	POSSIBLE SOLUTIONS
Remote control doesn't work.	• Make sure the batteries are fresh and installed properly.
Menu options can't be changed or selected.	• Try unplugging your TV for a few minutes, then plug it back in.
No picture or sound when any non-cable source is selected.	• Check to see if the source equipment has been turned on. • Make sure that the connections are secure on the back of your TV and on the source equipment.
Weak or no Stereo Sound when using a stereo VCR.	• Check to see if all the connections are secure. • Look in the Audio mode menu to see if all the settings are correct. • If you are using channel 3 or 4 to view your VCR, stereo sound will not be available.
The PIP inset is black or lacks contrast.	• Check to be sure that the PIP source is turned on. • Check that all the wires are connected properly. • Check to see if your input source for PIP is set correctly.
The PIP inset is "snowy" when the source is TV.	• Look to see if the TV/VCR button on your VCR has the TV selected or change the PIP to another source.
Time is incorrect.	• Make sure the time was set initially. Probably power was lost. • Reset clock manually.

Glossary

A list of definitions for some of the words found in this guide.

75 OHM RF CABLE — The round cable that comes from an off-air antenna or cable service provider. Each end looks like a hex shaped nut with a wire sticking through the middle, and it screws onto the threaded jack on the back of your TV.

A/V CABLES — Audio/Video cables. Three cables - Right audio (red), Left audio (white), and Video (yellow). A/V cables are used for stereo playback of videocassettes and for higher quality picture and sound from other A/V devices.

A/V DEVICE — Any device that produces video or sound (VCR, DVD, cable box, or television).

ADD — This function lets you add new channels to the channel list in memory that you'll scroll through when using your remote.

AMPLIFIER — An external device that amplifies sound from a television, CD player, VCR, DVD or other A/V device.

ANALOG TV — Traditional method of representing a television signal as a replica (analog) of the original picture and sound.

ANTENNA — The physical receiver of television signals sent over the air. A large metal piece of equipment does not always have to be visible for your home to be using an antenna.

ASPECT RATIO — The ratio of the horizontal dimension to the vertical dimension of a picture. Standard television in the U.S. today is generally transmitted and displayed in a 4:3 aspect ratio. High-Definition television will normally be formatted in a wider aspect ratio, assumed to be 16:9.

CAPTIONS — A form of subtitling that writes out the dialog for your program on the screen.

DELETE — This function lets you remove channels that you don't watch from the channel list in memory.

DIGITAL TV (DTV) — A new method of representing a television signal as a series of binary numbers (1s and 0s). This method allows the signal to be manipulated to eliminate redundancy and dramatically increase picture and sound quality.

DOLBY DIGITAL — Dolby Digital Cinema Sound is made possible by a new digital coding technique called Dolby AC-3. Dolby AC-3 produces high-quality, 5.1 channel surround sound which is six discrete separate channels for a full range of sound. Each channel can carry a different signal simultaneously (front center, front left, front right, surround left, surround right and subwoofer).

Glossary (Continued)

A list of definitions for some of the words found in this guide.

FAVORITE CHANNELS	This function created a customized list of your favorite channels. You can access this group of channels with the SURF button on the remote by pressing SURF repeatedly.
INPUT	Refers to the jack that receives a signal into the TV, VCR or other A/V device.
JACK	A connection on the back of a TV, VCR, or any other A/V device. This includes the RF jacks and the Audio/Video jacks that are color-coded.
MODE	The mode determines the type of device (TV, VCR, Cable, etc.) that the remote is controlling; remote operating mode.
MONO SOUND	Mono (monaural) sound is one channel of sound. On more than one speaker, all the speakers play the same audio.
OUTPUT	Refers to the jack that sends a signal out of a VCR, DVD, or other A/V device.
PIP	This is the most common way to refer to the Picture-In-Picture (PIP) feature.
SECOND AUDIO PROGRAMMING/SAP	Second Audio Programming (SAP) is another, separate, audio channel available with some programming. Choosing SAP often refers to listening to audio in another language, such as Spanish or French.
SIGNAL	Picture and sound traveling through cable, or over the air, to your television screen.
SOURCE	The term for the equipment that provides audio and video information to your TV. Antenna, VCR, DVD players, and Cable Boxes are examples of sources.
STEREO SOUND	Stereo (stereophonic) sound refers to audio that's divided into right and left sides.
TEXT	Arbitrary text not related to the program.
TUNER	Any device that picks up broadcast signals and turns them into picture and sound.

Product Specifications

Models	C34W37
Horizontal Size (inches)	41.7
Height (inches)	24.7
Thickness (inches)	23.2
Weight (lbs)	168.2
Power requirement	120V, 60Hz
Television system	American TV Standard, NTSC, ATSC with STB
Television Channel	VHF: 2 - 13 UHF: 14 - 69 CATV: 1 - 125 CADTV: 1 - 135
Power consumption (W)	220W
Antenna	75 ohm external terminal for VHF/UHF
Audio Output (W)	7W x 2
Supplied accessories	Remote control, batteries 2 size AA (Alkaline battery)
Screen Aspect Ratio	16 : 9
External input ports	Video/Audio input (4 set) Video output (1 set) S-Video input (3) Component input (2 set) Variable audio output (1 set) DVI-HDTV input (1) Digital audio optical input (2) Digital audio optical output (1) Calibration port (1) Antenna port (2)

Design and specifications are subject to change without notice.

© Copyright 2003, Zenith Electronics Corporation

ZENITH ELECTRONICS CORPORATION
Direct-View TV LIMITED WARRANTY – USA

Zenith will repair or replace your product, at Zenith's option, if it proves to be defective in material or workmanship under normal use, during the warranty period ("Warranty Period") listed below, effective from the date ("Date of Purchase") of original consumer purchase of the product. This warranty is good only to the original purchaser of the product and effective only when used in the United States, excluding U.S. Territories.

WARRANTY PERIOD:	**HOW SERVICE IS HANDLED:**
LABOR: 90 days from the Date of Purchase. **PARTS: One Year** from the Date of Purchase. **PICTURE TUBES: 2 Years** from the Date of Purchase. ∗ Parts replaced are warranted for the remaining portion of the original warranty period.	**In-Home Service:** Please retain dealer's dated bill of sale or delivery ticket as evidence of the Date of Purchase for proof of warranty, and submit a copy of the bill of sale to the service person at the time warranty service is provided. **Please call 1-877-9Zenith (1-877-993-6484) to locate your nearest Zenith Authorized Service Center.** Replacement parts may be new or factory remanufactured. Visit our website at **http://www.zenithservice.com**

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT ANY IMPLIED WARRANTY IS REQUIRED BY LAW, IT IS LIMITED IN DURATION TO THE EXPRESS WARRANTY PERIOD ABOVE. ZENITH WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL OR PUNITIVE DAMAGES OF ANY NATURE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, INCLUDING WITHOUT LIMITATION, LOST REVENUES OR PROFITS, LOST OR CORRUPTED PROGRAMMING OR DATA, OR ANY OTHER DAMAGE WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights that may vary from state to state.

THIS LIMITED WARRANTY DOES NOT APPLY TO:

- Damages or operating problems that result from shipping, installation, adjustment of user controls, calibration, maintenance or failure to maintain, or separate system components; and
- Damages or operating problems that result from normal wear and tear, misuse, abuse, operation outside environmental specifications or contrary to the requirements or precautions in the Operating Guide, accident, lightning strikes or other natural causes, unauthorized modification or alteration, incorrect electrical current or voltage, reception problem caused by inadequate home antenna or faulty antenna connections, computer software, institutional or commercial use, or other causes not arising out of defect in material or workmanship.

The cost of repair or replacement under these excluded circumstances shall be borne by the consumer.

CUSTOMER INTERACTIVE CENTER NUMBERS:

For nearest Authorized Service Center, Where to buy, Product Assistance, or Customer Assistance	**Call 1-877-9Zenith (1-877-993-6484) (Monday - Friday, 7 AM - 8 PM CT and Saturday, 8 AM - 5 PM CT) and select an appropriate option from the menu.** **Or visit our website at http://www.zenithservice.com**

ZENITH ELECTRONICS CORPORATION
2000 MILLBROOK DRIVE
LINCOLNSHIRE, IL 60069

Zenith Part No. 206-03890

P/N : 3828VA0395A ⓑ (AC02SA)